

Wash with tooth brush and soap before polish



2/20/2013

C. K. Grundke

78

Select recommended polish and wheel



2/20/2013

C. K. Grundke

79

Charging felt wheel with cerium



2/20/2013

C. K. Grundke

80

Make sure polish stays in liquid form – like heavy cream



2/20/2013

C. K. Grundke

81



Make sure entire surface is polished





If shaping and prepolish was done right – 2 to 4 minutes will be max time needed



Critiquing the cab.



2/20/2013

C. K. Grundke

86



Creating reverse bevel on bottom edge.

2/20/2013

C. K. Grundke

87



The End

**A “Thanks” to Wanda Matjas who
took the pictures while I
demonstrated to the class.**